Toggle display of fisheye-corrected images

Switching between correction and original screens

Snapshots and video clips of fisheye-corrected images can be switched between display modes.

Click on each image and then click on the fisheye correction icon ( ) to switch between the fisheye corrected layout and the original (fisheye) image.

Original (fisheye) mode

Fisheye correction mode