Playback of event notification screen video in Direct mode

The video displayed on the event notification screen can be played back in Direct mode. This function is useful when an event is longer than 10 seconds.

1. Click on the camera icon for the event you want to play.

2. The camera will move to the Direct mode of the Camera Details screen, and the video of the time period when the event occurred will be played back.