Switch between corrected and original screens (fisheye-corrected images)

Fisheye-corrected image events can be switched between display modes. Scrolling can also be used to zoom in and out and change the orientation.

Click on each image and then click on the fisheye correction icon ( ) to switch between the fisheye corrected layout and the original (fisheye) image.

Original (fisheye) mode

Fisheye correction mode