Delete a service

Setting up remote.it · https://manual.amnimo.com/en/docs/setting-up-remote-it/delete-a-service/

Here is how to delete a registered service. Deleting a service will also unshare the service.

1. Check the services to be deleted and click [Delete Service].

2. [Click Delete to complete deletion of the service.