Unshare services

Setting up remote.it · https://manual.amnimo.com/en/docs/setting-up-remote-it/unshare-services/

Learn how to cancel service sharing.

1. Check the items you want to cancel service sharing and click [Unshare].

2. [Click Delete to unshare the service.