Delete Viewer

Video Wall Setup and Operation · https://manual.amnimo.com/en/docs/video-wall-setup-and-operation-en-2/delete-viewer/

Unnecessary viewers can be deleted by following the steps below.

Open the viewer you wish to delete and click Delete from the icon in the upper right corner of the screen.



When a confirmation screen appears, click Yes.

