Enable streaming functionality

Video Wall Setup and Operation · https://manual.amnimo.com/en/docs/video-wall-setup-and-operation-en/enable-streaming-functionality-2/

NOTE

Application is required to use the streaming function.

When the streaming function is turned on, you can view live video on the video wall.