What you need to prepare

What you need to prepare · https://manual.amnimo.com/en/docs/what-you-need-to-prepare-en-4/what-you-need-to-prepare-4/

- **SIM card** (SIM size conversion adapters are deprecated)

  Please have one available for mobile connections.

- Please refer to the IoT Router User's Manual for specifications and standards.

NOTE

For AR10-000JP (without communication module) models, a SIM is not required.

- **PC for configuration**

  Required to configure various settings of the IoT router.

  This manual uses Windows 10.

- **LAN cable** (recommended category: CAT5e or higher)

  Required to connect IoT router and PC.