About This Book

Notes on this document

- The contents of this document are subject to change without notice.
- Reproduction or reprinting of the contents of this document, in whole or in part, without permission is prohibited.
- While every effort has been made to ensure the accuracy of the information contained in this document, if you have any questions or find any errors, please contact our customer support.

Contact : Amnimo Customer Support
E-mail : support@amnimo.com
URL : https://support.amnimo.com/

- Please note that revisions may not be made for specification changes, structural changes, or changes in parts used that are not considered to be particularly detrimental to functionality/performance.

Manual List

general

- amnimo gateway series CLI User's Manual (this manual)
- amnimo gateway series GUI User's Manual
- Device Management System Manual

amnimo X/G/R Series

- amnimo X Series AI Edge Gateway User's Manual
- amnimo X Series AI Edge Gateway Startup Guide
- amnimo G Series Edge Gateway User's Manual
- amnimo G Series Edge Gateway Startup Guide
- amnimo R Series IoT Router User's Manual
- amnimo R Series IoT Router Startup Guide
- amnimo gateway series developer's manual (amnimo G/X series only)
- Edge Gateway Series Open Source Software License Agreement

amnimo C Series

- amnimo C Series Compact Router User's Manual
- amnimo C Series Compact Router Startup Guide
- Compact Router C Series Open Source Software License Agreement

How to see compatible models

This manual is compatible with multiple models. Icons for supported models are shown below.

- If the following icons appear at the beginning of a chapter or section, it corresponds to the model described in that chapter or section.
- If the following icons are not indicated at the beginning of a section or subsection, it corresponds to the model with the icon notation of the chapter or section to which it belongs.

	Indicates support for indoor-type AI edge gateways.
	Indicates support for indoor-type edge gateways.

	Indicates support for outdoor-type edge gateways.
	Indicates support for indoor type IoT routers.
	Indicates support for outdoor type IoT routers.
	Indicates that the router is compatible with indoor type compact routers.
	Indicates support for indoor type compact routers with wireless LAN.
	Indicates support for compact routers with outdoor-type wireless LAN.

Command Description

The command format of this manual is written as follows

writing on the surface (e.g. an address on an envelope)	**Description.**
value	Bolded type is a fixed value. If italicized in bold, it is a setting parameter or a keyword. It cannot be omitted.
[A | B]	Select A or B. May be omitted.
	Select A or B. It cannot be omitted.

writing on the surface (e.g. an address on an envelope)	Description.
[0 - 9]	Select one of the values from 0 to 9. May be omitted.
<0 – 9>	Select one of the values from 0 to 9. It cannot be omitted.
	Indicates a line break (Enter key input).

Output format description

The format of the output format in this document is described as follows

Parameters for which a setting must exist

```
parameter PARAMETER
```

Option Setting Parameters

```
PARAMETER
```