Configure proxy server settings

Advanced Settings · https://manual.amnimo.com/en/docs/advanced-settings/configure-proxy-server-settings/

This section describes the proxy server settings.

NOTE

In group settings, it is also possible to grant permissions restricted to "standby ports" only.

From the side menu, click Advanced Settings & Controls - Proxy Server Settings.

The "Proxy Server Settings" screen appears.



Configure proxy server settings.

❶ Slide the toggle to enable the proxy server.

❷ Enter the listening port number. The default value is 8080.

❸ If a connection permission address is required, check the box and enter the source address.

❹ Set the destination port number.

❺ Set the SSL/TLS connection destination port number.



❻ Select deny or allow access control.

❼ Set the destination port number and SSL/TLS connection port number.

❽ White list/black list registration for specific FQDNs and URLs.

❾ Configure user authentication and access log settings.



When settings are complete, click on "Configure".