Configure SYSLOG settings.

Advanced Settings · https://manual.amnimo.com/en/docs/advanced-settings/configure-syslog-settings/

Configure settings for saving the SYSLOG of this product.

Click [Advanced Settings and Controls] - [SYSLOG Settings] in the side menu.

The "SYSLOG SETTINGS" screen appears.



Set the following items (1) to (2) and click the "Set" button.

Slide the ❶ toggle to set SYSLOG as enabled.

❷ Select the level of log output.



SYSLOG settings are made.