CPU Operation Setting

Advanced Settings · https://manual.amnimo.com/en/docs/advanced-settings/cpu-operation-setting/

NOTE

AI Edge Gateway (amnimo X series) and Compact Router (amnimo C series) do not have this feature.

Display CPU operation settings

Displays CPU operation settings.

Click on the side menu [Advanced Configuration and Control] - [CPU Operation Settings].



The set CPU operating frequency is displayed on the "CPU Operating Settings" screen.

CPU Operation Setting

On the "CPU Operation Settings" screen, select the CPU operating frequency you wish to set from the "Operation" pull-down menu.



[Click Settings.



Information on CPU operation settings is updated.