Configure remote.it settings

Advanced Settings · https://manual.amnimo.com/en/docs/advanced-settings/diagram-in-brief-configure-remote-it-settings/

Configure this product to use remote.it.

From the side menu, click Advanced Settings & Controls - remote.it Settings.



The "remote.it settings" screen will appear.

Slide the toggle to set remote.it to active.



For Edge Gateway / AI Edge Gateway / IoT Router, click Next.

For compact routers, perform the following precautionary tasks

NOTE

For compact routers (amnimo C series), the registration code must be registered.

Registration codes must be obtained separately from the remote.it web page.

- Refer to the " amnimo C Series Compact Router Startup Guide " or other reference manuals for configuration instructions.

Edge Gateway AI Edge Gateway IoT Router	Compact Router
	

You can delete the registered registration code by clicking "Settings" without entering the registration code.