Set the DMS settings.

Advanced Settings · https://manual.amnimo.com/en/docs/advanced-settings/set-the-dms-settings/

Set up to use Device Management System.

ALERT

To enable smooth device management, the factory default setting for DMS on the device side is " **enabled** ".

Regardless of whether this service is used or not, Internet communication is performed when the DMS setting is enabled. Since communication costs are incurred when using mobile functions, please **disable** the DMS setting if you do not use this service.

Display DMS settings

Displays DMS settings.

Click on the side menu [Advanced Configuration and Control] - [DMS Settings].



The "DMS Settings" screen displays the current DMS setting status.

Enable/disable DMS settings

Enables/disables DMS settings.

On the "DMS Settings" screen, click the toggle to change the setting to [Enable] or [Disable], then click the [Settings] button.



Information on DMS settings will be updated.