Set the host name

Advanced Settings · https://manual.amnimo.com/en/docs/advanced-settings/set-the-host-name/

Set the host name of this product.

From the side menu, click Advanced Configuration and Control - Host Name Settings.

The "Host Name Settings" screen appears.



Enter a host name in the "Host Name" field and click the "Set" button.



The host name is set.