Delete camera

Camera Setting · https://manual.amnimo.com/docs/camera-setup-and-en/delete-camera-2/

Cameras connected to the router can be deleted by the customer.

NOTE

- The service must be stopped before the camera can be deleted. To stop the service, please refer to the previous section " Check Status and Stop Service ".
- For cameras with direct connection (no gateway), please request Amnimo sales representative to delete the camera after deactivating the service in advance.

1. On the camera in question, click the icon and then click Status.

2. From the Delete Camera item, click Delete.

3. Click "Yes" after confirming the notes displayed.