Device Activation

https://manual.amnimo.com/docs/uncategorized/device-activation/

When using the Cloud Video Recorder for the first time, the router must be activated for the device.

This section describes the initial setup procedure, including device activation. (Click on each item to view the procedure.)

1. Click ▼ and select Devices.

2. Click on for the device you wish to activate and click on Gateway Settings.

3. Click "Enable" when the settings window opens.

4. Click Yes when the confirmation window opens. (This process may take several minutes.)

5. The display will change to "Activating".

6. When activation is complete, the Deactivate button becomes active.