common setting

Various settings · https://manual.amnimo.com/docs/various-settings-en/common-setting-2/

The following settings can be configured in the common settings.

- **Thumbnail Refresh Cycle** : Select the refresh cycle for thumbnails of all cameras.
- **Live Streaming Timeout Duration**: Select the amount of time after the live video is played before the live video is automatically stopped.
  Only "minutes" can be selected as the unit.

1. [From the Common Settings tab, change various settings.

2. [Click "Save" to save the settings.