Transition from the video wall to the camera detail screen


Video Wall Setup and Operation · https://manual.amnimo.com/docs/video-wall-setup-and-operation-en/transition-from-the-video-wall-to-the-camera-detail-screen/

The camera detail screen can be accessed from the video wall.


NOTE

The images are from an integrated video management system, but the basic operation method is the same.

Move the mouse over the area of the camera for which you want to view camera details, and click on "View in Camera Details" when it appears.



The camera detail screen appears.


統合ビデオ管理システム - カメラ詳細 -
メニュー
99+
AX11-
DS-
IU
AX11-TORY
amoVMS
GV-BX2700
M2025-LE
Automation1992021
AutomationGA323
AXISM1114-Cam1
AXISM1114-Cam2
Removed
CLOUD
DIRECT
2024-09-18 17:33:58
9/18 (水) 17:33:59
9/17 17:39
9/18 17:44
LIVE
8:00
21:00
9/18
03:00
06:00
09:00
12:00
15:00
9/12
9/13
9/14
9/15
9/16
9/17
9/18
x1
© amnimo Inc.
利用規約