Show history

Basic operation · https://manual.amnimo.com/en/docs/basic-operation-en-2/show-history/

History displays a list of device events and operation history.

Check the history of all devices

History displays a list of events and operation history. You can also check the source to see where the event was notified from.

Examples of events and operation history displayed in the history

Device Management System Operation History

- Create, edit, and delete devices
- Start/stop PoE and USB power supply (except when using IoT router)
- Reboot device
- Upload / Download Files
- Firmware update
- Update configuration files
- Task execution status

Device status monitoring events

- Device communication status normal/abnormal
- Device status normal/abnormal

Device self-diagnostic events

- Link up / down for each Ethernet port (except when using an IoT router)
- AC power supply stopped/restored

- SIM card enable/disable

Check individual device history

Examples of events and operation history displayed in the history

Device Management System Operation History

- Create, edit, and delete devices
- Start/stop PoE and USB power supply (except when using IoT router)
- Reboot device
- Upload / Download Files
- Firmware update
- Update configuration files

Device status monitoring events

- Device status normal/abnormal
- Device communication status normal/abnormal

Device self-diagnostic events

- Link up / down for each Ethernet port (except when using an IoT router)
- AC power supply stopped/restored
- SIM card enable/disable