
# Open custom maps from various locations.

Custom map setup and operation · https://manual.amnimo.com/en/docs/custom-map-setup-and-operation-en-2/open-custom-maps-from-various-locations/


Custom map views can be opened from multiple locations.

## Open from the [ Cloud Storage Videos / Images ] menu

[In the Cloud Storage Videos/Images, click  Map Location  in the thumbnails.





A custom map will open with the camera plotted on it.




## Open from selected camera (CLOUD/DIRECT)

Select a camera from the camera detail screen and click on the map icon.




A custom map will open with the camera plotted on it.

