Open custom maps from various locations.

Custom map setup and operation · https://manual.amnimo.com/en/docs/custom-map-setup-and-operation-en/open-custom-maps-from-various-locations-2/

Custom map views can be opened from multiple locations.

NOTE

The images are from an integrated video management system, but the basic operation method is the same.

Open from the [Cloud Save Video / Image] menu

1. [In the Cloud Storage Videos/Images, click Map Location in the thumbnails.
2. A custom map will open with the camera plotted on it.

Open from selected camera (CLOUD/DIRECT)

1. Select a camera from the camera detail screen and click on the map icon.
2. A custom map will open with the camera plotted on it.