Change event status

Handle events · https://manual.amnimo.com/en/docs/handle-events-en/change-event-status/

The status of detected events can be changed from the Event List screen.

Go to [Menu] > [Event List] and click on for the event whose status you want to change, and the Change Event Status button will appear.

Change status according to event status.

	sense (e.g. sensor)
	in process
	completion

NOTE

Once the event status is changed, it cannot be restored.