1. set up the device

Initial setting · https://manual.amnimo.com/en/docs/initial-setting-dms/1-set-up-the-device/

Device Management Systemto be used, the device must be set up in advance to establish communication with Device Management System.

NOTE

Refer to your product's Startup Guide for setup instructions.

- AI Edge Gateway Startup Guide
- Edge Gateway Startup Guide
- IoT Router Startup Guide
- Compact Router Startup Guide



Once setup is complete and communication between the device and Device Management Systemis established, configuration files can be downloaded to the device and configuration changes can be made remotely as well.