Disable Services

Setting up remote.it · https://manual.amnimo.com/en/docs/setting-up-remote-it/disable-services/

If you do not want to be able to connect to the Edge Gateway / IoT Router with a registered service, you must disable that service.
Here is how to disable the service. Disabling a service does not delete the service.

1. [Click Disable.

2. [Click Disable to complete the deactivation.