Replace the device

Useful Features · https://manual.amnimo.com/en/docs/useful-features/replace-the-device/

WARNING

The features listed on this page are not available for Amnimo Portable.

When replacing a device (e.g., replacing a failed device with a new device), refer to the following procedure to replace the device.

WARNING


The device exchange function is available only if all of the following conditions are met

- The device to be replaced is already activated.
- Unenabled devices exist for the same device type
- Failed device and new device belong to the same tenant

Device Replacement Procedure

Use device profiles when replacing devices. Please create a device profile in advance.
⇒See " How to create a device profile " in " How to create a device profile ".

From the device list, click Device Replacement for the activated device you wish to replace.



Select a device type/device profile and arbitrarily specify the name of the device after the replacement of the current device is completed.



The device name of the current device before the change will automatically be taken over by the device name of the new device.

To avoid duplicating the device name of the new device after the replacement is completed, the

device name of the current device after the replacement is completed is appended with "Replaced-" by default.

(Example)

Current device: (Before replacement) Sample → (After replacement) Replaced-Sample

New device: (Before replacement) Test → (After replacement) Sample

[Click Confirm.



Once the new device is connected to the Internet, the device exchange is complete.