Switching screens and saving initial images

Video playback and operation · https://manual.amnimo.com/en/docs/video-playback-and-operation-en/switching-screens-and-saving-initial-images-2/

If **fisheye correction is enabled**, you can switch between the original fisheye image and the fisheye corrected image. You can also save the initial image as you like when you click on the camera.

NOTE

The images are from an integrated video management system, but the basic operation method is the same.

When fisheye correction is enabled, the following functions are available in LIVE playback.

Switching between correction and original screens

Click the fisheye correction icon to switch between the fisheye corrected layout and the original (fisheye) image.

Image after clicking the fisheye correction icon