# Transition from the video wall to the camera detail screen

Video Wall Setup and Operation · https://manual.amnimo.com/en/docs/video-wall-setup-and-operation-en/transition-from-the-video-wall-to-the-camera-detail-screen/

The camera detail screen can be accessed from the video wall.


**NOTE**

The images are from an integrated video management system, but the basic operation method is the same.

**Move the mouse over the area of the camera for which you want to view camera details, and click on "View in Camera Details" when it appears.**




The camera detail screen appears.


統合ビデオ管理システム - カメラ詳細 -
メニュー
99+
AX11-
DS-
IU
AX11-TORY
amoVMS
GV-BX2700
M2025-LE
Automation1992021
AutomationGA323
AXISM1114-Cam1
AXISM1114-Cam2
Removed
CLOUD
DIRECT
2024-09-18 17:33:58
9/18 (水) 17:33:59
9/17 17:39
9/18 17:44
LIVE
8:00
21:00
9/18
03:00
06:00
09:00
12:00
15:00
9/12
9/13
9/14
9/15
9/16
9/17
9/18
x1
© amnimo Inc.
利用規約