
Edit the camera icon

Web Map Setup and Operation · https://manual.amnimo.com/en/docs/web-map-setup-and-operation-en/edit-the-camera-icon/

The camera icon can change its position and orientation.

From the camera list, select the name of the camera whose camera icon you wish to edit and click on the settings icon.



Click to change the orientation of the camera icon, drag it to a new position, and then click [Decide]. (In this step, only the orientation is changed.)



Confirm that the camera orientation has been changed.

