What is Device Management System?

The amnimo Cloud's Device Management Systemmakes it easy to monitor and maintain edge gateways in remote locations.

The primary functions of the Device Management System are as follows

- Remote monitoring of devices
- Remote distribution and retrieval of device configuration files
- Remote firmware updates
- Syslog file acquisition

NOTE

- You must apply to use the features of the Device Management System. Please contact your sales representative if you wish to use this service.
- The following settings in this document must be completed in order to proceed with Device Management System configuration.
  - Step 1 Activate/connect
  - Step 2 Sign in to the Edge Gateway
  - Step 3 Configure the edge gateway settings
- For detailed information on how to use the Device Management System and its settings, please refer to the following
  ⇒ Device Management System Manual