Reboot the device

1. Click ▼ and select Devices.

2. Click on for the device you wish to reboot, then click on Gateway Settings.

3. [Click Restart.

4. Select Software Reboot or Hardware Reboot.
    1. Software Restart

    2. Hardware reboot

5. Click "Restart" for each of the confirmation screens that appear.
    1. Software Restart

    2. Hardware reboot

       Review the notes, check the agreement, and click Restart to reboot.