
Configure GUI settings

Advanced Settings · https://manual.amnimo.com/en/docs/advanced-settings/configure-gui-settings/

Configure settings related to the GUI setup screens described in this manual.

Click on the side menu [Advanced Settings and Control] - [GUI Settings].



The "GUI Settings" screen appears.

Configure GUI settings.

Select "HTTP" or "HTTPS" as the protocol.



Enter the port number.

NOTE

- The port number can be set in the range of 1 to 65535.
- The standard port 80 is used for HTTP, and port 443 for HTTPS.
- Note that if the port number is changed, the client must specify that port number to connect.



[Click Settings.

The GUI is configured.