Configure SSH settings

Advanced Settings · https://manual.amnimo.com/en/docs/advanced-settings/configure-ssh-settings/

Configure settings to connect to this product via SSH.

SSH must be enabled when connecting to this product using a terminal emulator or similar device.

Click [Advanced Settings/Controls] - [SSH Settings] on the side menu.



The "SSH Settings" screen appears.

Slide the toggle to set SSH as enabled.



Set the following (1) to (2).

❶ Change the port number if necessary.



NOTE

- The port number can be set in the range of 1 to 65535.
- SSH uses port 22 as standard.
  Note that if the port number is changed, the client must specify that port number to connect.

❷ By checking the "Enable keep-alive" checkbox, keepalive packets can be sent periodically to prevent SSH connections from timing out.



Set the encryption method.

❶ Select "Recommended setting" or "Individual selection" as the encryption method to be used.

- If you selected "Recommended Settings," go to Step 5.



❷ If "Individual Selection" is selected, check the checkbox for the encryption method to be used.



Click the [Settings] button.

SSH is configured.