Set the time zone

Advanced Settings · https://manual.amnimo.com/en/docs/advanced-settings/set-the-time-zone/

Set the time zone for your product.

Click on the side menu [Advanced Settings & Control] - [Time Zone Settings].

The "Time Zone Settings" screen will appear.



Set the following items (1) to (2) and click the "Set" button.

❶ Select "Region".

❷ Select "Place Name".

