Screen configuration of this product

Basic operation · https://manual.amnimo.com/en/docs/basic-operation-en-3/screen-configuration-of-this-product/

This section describes the basic screen structure and side menu of the product.

screen configuration

The contents displayed on the screen and the setting and control items vary depending on the authority of the user who is signed in.

For information on user privileges, see "Configuring Account Settings " and "Configuring Group Settings ".



reference screen

No.	(data) item	Description.

❶	Side menu display button	Click to hide or show the ❺ side menu.
❷	host name	The host name of this product is displayed.
❸	Language	The current language setting is displayed. Click to switch between English and Japanese.
❹	account name	The account name of the user who is signed in is displayed. Click to select [Sign Out]. Sign Out."
(in Japanese) ❺	side menu	The menu for operating this product will be displayed. Side Menu."
(in Japanese) ❻	main area	Clicking on it will display the screen according to the menu selected in the ❺ side menu.

side menu

NOTE

The items displayed will vary depending on the permissions of the group settings.

menu	sub-menu	Description.
simplified setup	long vowel mark (usually only used in katakana)	This menu is provided to configure the mobile communication and interface settings necessary to run this product on a single screen.
Equipment Information	long vowel mark (usually only used in katakana)	This menu is used to display device and firmware information, and to check SIM information.
Operational Information	interface	This menu is used to display interface settings.
	routing	This menu is used to display routing settings.
	Mobile Communications	This menu is used to display mobile communication settings.
	wireless LAN	This menu is used to display the wireless LAN settings.

menu	sub-menu	Description.
IPsec	This menu is for checking the IPsec connection status.	
DHCP Lease	This menu is used to check the DHCP lease status.	
storage	This menu is used to display storage settings. You can also add partitions.	
Power Over Ethernet	This menu is used to display PoE settings. You can also perform a PoE reset for each interface.	
Contact change history	This menu is used to check the contact change history.	
SYSLOG	This menu is for displaying SYSLOG. You can search SYSLOG by specifying keywords and download SYSLOG files.	
AMLOG	This menu is for displaying AMLOG. You can search AMLOG by specifying keywords and download AMLOG files.	
Time display	This menu is used to display the time set in this product.	
Detailed setting and control	Package Repository Settings	Displays a screen for setting up credentials for the package repository.

menu	sub-menu	Description.
Host Name Setting	Displays a screen for setting the host name of this product.	
time zone	Displays a screen for setting the time zone for this product.	
Account Settings	Displays a screen for setting up the account.	
Group settings	Displays a screen for configuring group settings.	
Mobile Communication Settings	Displays a screen for configuring mobile communication settings.	
Wireless LAN Settings	Displays a screen for configuring wireless LAN settings.	
PPP (PPPoE) settings	Displays a screen for making PPP (PPPoE) settings.	
Interface Settings	Displays a screen for configuring interface settings.	
Static Routing Configuration	Displays a screen for static routing configuration.	
Filter settings	Displays a screen for filter settings.	
NAT Configuration	Displays a screen for configuring NAT settings.	

menu	sub-menu	Description.
IPsec Settings	Displays a screen for IPsec configuration.	
DNS Settings	Displays a screen for configuring DNS settings.	
DHCP Configuration	Displays a screen for making DHCP settings.	
DHCP Relay Settings	Displays a screen for configuring DHCP relay settings.	
Proxy Server Settings	Displays a screen for configuring proxy server settings.	
Time setting	Displays a screen for setting the time for this product.	
SSH Configuration	Displays the configuration screen for accessing this product via SSH.	
Storage Settings	Displays the storage settings screen	
Schedule setting	Displays a screen for setting up a schedule for this product.	
PoE Configuration	Displays the PoE setting screen	
SYSLOG setting	Displays a screen for configuring SYSLOG settings for this product.	

menu	sub-menu	Description.
CPU operation setting	Displays the CPU operation setting screen	
DMS Settings	Displays the DMS setting screen	
Nx Witness Settings	Displays the Nx Witness configuration screen	
Configure remote.it settings	Displays the remote.it settings screen	
GUI Settings	Displays the configuration screen for setting up this product via GUI.	
restart	long vowel mark (usually only used in katakana)	Displays a screen for restarting the product.
firmware	long vowel mark (usually only used in katakana)	Displays a screen for updating the firmware of this product.
setup file	long vowel mark (usually only used in katakana)	Displays a screen for manipulating the product's configuration file.
users' manual	long vowel mark (usually only used in katakana)	Display user's manual