smart search

Direct mode · https://manual.amnimo.com/en/docs/direct-mode/smart-search/

Smart Search is a function that searches for the corresponding video when there is movement within a specified range.
E.g., checking people coming and going at night, checking vehicles entering and leaving the premises, etc.

1. Select the camera to be operated and click the Smart Search icon on the screen.

2. Drag to specify the area where you want to do a smart search. The time of the movement is displayed in red on the timeline bar.

   You can also select multiple areas by pressing the Shift key + drag.

3. On the timeline bar, click the time you wish to view the video.

4. Clicking Play will sequentially play back the images that have been moved.

   - : Sequential playback of smart search detection motions. Click again to return to normal playback.
   - - / + : Adjusts the video playback speed.
   - < / >: Play the previous / next motion.
   - |◀ / ▶|: Play the oldest motion. / Play the most recent motion.

5. Click the Smart Search icon again to finish the Smart Search operation.